



1. Insert Spreaders(left and right) into the Connector.
2. Unwind SkyTails.
3. For more stability, tie SkyTails® together.
4. Attach QuikClip® to Bridle Loop (Front of Kite). Top Loop for Light to Medium Wind  
Bottom Loop for Strong Wind.