ASSEMBLY INSTRUCTIONS

R2D2™



1. Insert the Main Spreaders, left and right, into the Main Connector.



2. Insert the Top Spreaders, left and right, into the Top Connector.



3. Insert the Bottom Spredares, left and right, into the Bottom Connector.



Front Side of Kite



4. Unwind SkyTails™. For more stability, tie them together.



5. Attach QuickClip® to Bridle Loop
Top Loop: For Light to Medium Wind
Bottom Loop: For Strong Wind

LAUNCHING - ASSISTED LAUNCH

- The kite requires a minimum wind of 7 mph / 11.3 kph. Let out approximately 75 feet / 22.86 m of line and have an assistant hold the kite.
- With your back to the wind, release the kite and take a few steps backwards, the kite will rise into the air. Tug line to gain altitude, let out line to gain distance.
- For storage, reverse assembly steps and place into package. Store your kite in a cool dry place. Excessive heat and/or sunlight can damage the package and kite.

KITE SAFETY

WARNING! Do not fly near overhead power lines.
WARNING! Do not use near overhead power lines or during thunderstorms.
WARNING! Not suitable for children under 3 years due to small parts.
WARNING! Not suitable for children under 3 years due to long cord.
Please remove all packaging material before giving the toy to child.
Keep important information for future reference.

Never fly near an airport.
Never fly over people.
Never fly in thunderstorms.
Never fly near busy streets.
Never fly near overhead power lines.

Never try to retrieve your kite from power lines.
Call your local power company for assistance.