



**1** Pull Bridle Lines Tight Before Assembly.



**Back of Kite**

**Front of Kite**



## LAUNCHING - ASSISTED LAUNCH

- The kite requires a minimum wind of 11.3 kph / 7 mph. Let out approximately 22.9 m / 75 feet of line and have an assistant hold the kite.
- With your back to the wind, release the kite and take a few steps backwards, the kite will rise into the air. Tug line to gain altitude, let out line to gain distance.
- For storage, reverse assembly steps and place into package. Store your kite in a cool dry place. Excessive heat and/or sunlight can damage the package and kite.

## KITE SAFETY

**WARNING!** Do not fly near overhead power lines.  
**WARNING!** Do not use near overhead power lines or during thunderstorms.  
**WARNING!** Not suitable for children under 3 years due to small parts.  
**WARNING!** Not suitable for children under 3 years due to long cord.  
 Please remove all packaging material before giving the toy to child.  
 Keep important information for future reference.

Never fly near an airport.  
 Never fly over people.  
 Never fly in thunderstorms.  
 Never fly near busy streets.

Never fly near overhead power lines.  
 Never try to retrieve your kite from power lines.  
 Call your local power company for assistance.

# KITE SAFETY



Never fly near tall buildings or trees.



Never fly over people.



Never fly near an airport.



Never fly near busy streets.



Never fly in thunderstorms.



Never fly near overhead power lines.

## WARNING!

DO NOT FLY NEAR OVERHEAD POWER LINES.  
NEVER FLY OVER PEOPLE AS SPORT KITES ARE CAPABLE OF HIGH SPEEDS THAT CAN INJURE A PERSON ON CONTACT